

STEP 2: SECURE FRAMES WITH 2"THUMB SCREWS AND CORNER CONNECTORS (IF NEEDED).

